




## Time & date change instructions for: AcroPrint 2400


Example: Change the time from PM 10:20 to AM 11:30

1. Press the [F] button, and position the "▲" under the "TIME" mark. The "Hour" flashes. (The flashing means it can be changed.)




### Setting the "hour"

Press the [+] or [-] button to set at "AM 11" and press [E] button. At the same time, the flashing changes from "Hour" to "Minute".




2. **Setting the "Minute"**

Press the [+] or [-] button to set at "30" and press [E] button.



At the same time, the "Second" starts to run from "00" and the LCD screen only display "▲" under the "TIME" mark.



3. If you want to set another function, press the [F] button to continue setting.

If you finished setting the functions, press the [E] button again. The LCD screen will return to normal mode.

## Support benefits

- ✓ UK based support experts
- ✓ Unlimited calls
- ✓ Priority support
- ✓ Peace of mind
- ✓ Online Remote Support

## What it covers

- ✓ Troubleshooting
- ✓ Configuration advice
- ✓ Shift/rules set up assistance
- ✓ Transaction queries
- ✓ Reporting issues

## To get support

Call us on

**01908 281 000**



All our support personnel are fully trained and based in the UK. As a company we are ISO27001 accredited.



01908 281000

info@timesystemsuk.com

www.timesystemsuk.com

Time Systems (UK) Ltd, Systems House,  
Newport Road, Wavendon, Milton Keynes, MK17 8AA