



## Time & date change instructions for: GeoFace

The time and date change must be done at the terminal.

1. Press 'Menu' on the screen
2. Scan your face or Press 1:1 to enter Administrator ID and Password to access menu
  - a. Default Administrator ID is 999
  - b. Default Administrator Password is 999
3. Select Date/Time
4. Select Time
5. Change the time and press OK
6. Press Save to save the settings

## Support benefits

- ✓ UK based support experts
- ✓ Unlimited calls
- ✓ Priority support
- ✓ Peace of mind
- ✓ Online Remote Support

## What it covers

- ✓ Troubleshooting
- ✓ Configuration advice
- ✓ Shift/rules set up assistance
- ✓ Transaction queries
- ✓ Reporting issues

## To get support

Call us on

**01908 281 000**



All our support personnel are fully trained and based in the UK. As a company we are ISO27001 accredited.



01908 281000

info@timesystemsuk.com

www.timesystemsuk.com

Time Systems (UK) Ltd, Systems House,  
Newport Road, Wavendon, Milton Keynes, MK17 8AA