



Time & date change instructions for: GeoTime Wifi

The time and date change must be done at the terminal.

1. Press M/OK button to access menu
2. Enter any required authentication to access menu
3. Select System and press M/OK
4. Select Date/Time and press M/OK
5. Change time and press M/OK

Support benefits

- ✓ UK based support experts
- ✓ Unlimited calls
- ✓ Priority support
- ✓ Peace of mind
- ✓ Online Remote Support

What it covers

- ✓ Troubleshooting
- ✓ Configuration advice
- ✓ Shift/rules set up assistance
- ✓ Transaction queries
- ✓ Reporting issues

To get support

Call us on

01908 281 000



All our support personnel are fully trained and based in the UK. As a company we are ISO27001 accredited.



01908 281000
info@timesystemsuk.com
www.timesystemsuk.com

Time Systems (UK) Ltd, Systems House,
Newport Road, Wavendon, Milton Keynes, MK17 8AA