



Time & date change instructions for: ProxTime

2019 model onwards

The time and date change must be done at the terminal.

1. Press M/OK button to access menu
2. Enter any required authentication to access menu
3. Select System and press M/OK
4. Select Date/Time and press M/OK
5. Change time and press M/OK

Pre 2019 model

The time and date change must be done at the terminal.

1. Press M/OK button to access menu
2. Enter any required authentication to access menu the default is 999/999
3. Select Date/Time
4. Change the Time and press M/OK to save



All our support personnel are fully trained and based in the UK. As a company we are ISO27001 accredited.

Support benefits

- ✓ UK based support experts
- ✓ Unlimited calls
- ✓ Priority support
- ✓ Peace of mind
- ✓ Online Remote Support

What it covers

- ✓ Troubleshooting
- ✓ Configuration advice
- ✓ Shift/rules set up assistance
- ✓ Transaction queries
- ✓ Reporting issues

To get support

Call us on

01908 281 000



01908 281000

info@timesystemsuk.com

www.timesystemsuk.com

Time Systems (UK) Ltd, Systems House,
Newport Road, Wavendon, Milton Keynes, MK17 8AA